



CF111KD

BMW F850GS 2018-

Kit for left side			
ID	Description	Cat. No.	Pcs.
1	Frame		1
2	Bolt M12x100	986	2
3	Washer flat M12	803	2
4	Dural. roller d=52,4mm	1273	1
5	Dural. roller d=51mm	1274	1
6	Bolt M10x35	847	1
7	Washer flat M10	804	2
8	Plastic cover M12	X60	2
9	Plastic cover M10	X4	1
10	Nut M10	810	1
11	Washer M10 spring	801	1

Kit for right side			
ID	Description	Cat. No.	Pcs.
1	Rám		1
2	Bolt M12x110	946	2
3	Washer flat M12	803	2
4	Dural. roller d=11mm	1272	2
5	Sticker RD moto		2
6	Bolt M10x35	847	1
7	Washer flat M10	804	1
8	Plastic cover M12	X60	2
9	Plastic cover M10	X4	1
10	Bolt M8x30	834	1

We recommend using medium strength thread glue during assembly.

Mounting Instructions:

- 1.) On left of the motorcycle, take off the original bolts from top part of the motorcycle frame (as shown on attached picture).
- 2.) Now take the M12 ID.2 bolts and M12 ID.3 washers and push them through the ID.1 crash frame. Then, fit them with ID.4 (front) and ID.5 (rear) rollers and mount the assembly into the motorcycle frame.
- 3.) Then, affix it in the rear bottom part with M10 ID.6 bolt, ID.11 spring washer and ID.7 flat washer.
- 4.) Now take the right side and unscrew the original bolts from upper part of motorcycle frame (as shown on attached picture).
- 5.) Push the M12 ID.2 bolts and M12 ID.3 washers and push them through the ID.1 frame. On them, put the ID.4 dural rollers and mount the assembly into the motorcycle frame.
- 6.) Affix the frame at the bottom rear part with M10 ID.6 bolt and ID.7 washer.
- 7.) Finally, tighten the frames together in the front part using M8 ID.10 bolt.
- 8.) Now tighten all screws and place the plastic covers on top of the bolts.



Bolt M10 ID.6 +
Washer M10 ID.7

