



RDMOTO CZECH REPUBLIC
info@rdmoto.eu
www.rdmoto.eu

CF168

Aprilia Tuareg 660

Kit for left side

ID	Description	Cat.No.	Pcs
1	Crash frame - upper	CF168-L	1
2	Protector	PVPKN-0/16	1
3	Al insert to the protector	X131	1
4	Dural.roller l=68,5mm	101	1
5	Dural.bolt l=18mm	447	1
6	Bolt M10x55mm	1002	1
7	Bolt M10x60mm	850	1
8	Bolt M10x50mm	849	1
9	Al insert for bolt	X115	1
10	Plastic cover for bolt	X4	1
11	Dural.roller l=20mm	1404	1

Kit for right side

ID	Description	Cat.No.	Pcs
1	Crash frame - upper	CF168-P	1
2	Protector	PVPKN-0/16	1
3	Al insert to the protector	X131	1
4	Dural.roller l=68,5mm	101	1
5	Dural.bolt l=18mm	447	1
6	Bolt M10x55mm	1002	1
7	Bolt M10x60mm	850	1
8	Bolt M10x50mm	849	1
9	Al insert for bolt	X115	1
10	Plastic cover for bolt	X4	1
11	Dural.roller l=20mm	1404	1

We recommend using medium strength thread glue during assembly.

Right side :

Bolt M10x50mm
ID.8 + dural.roller under crash
frame l=20 ID.11 + Al insert for
bolt ID.9 + plastic cover for bolt
ID.10



Bolt M10x55mm
ID.6 to attach the dural roller to the
motorcycle frame l=68,5mm ID.4 +
dural.bolt under crash frame
l=18mm ID.5 + Al insert to the
protector ID.3 + protector ID.2 +
bolt M10x60mm ID.7 to attach the
crash frame to the dural screw.

Levá strana :



Bolt M10x50mm
ID.8 + dural.roller under crash
frame l=20 ID.11 + Al insert for
bolt ID.9 + plastic cover for bolt
ID.10

Bolt M10x55mm
ID.6 to attach the dural roller to the
motorcycle frame l=68,5mm ID.4 +
dural.bolt under crash frame
l=18mm ID.5 + Al insert to the
protector ID.3 + protector ID.2 +
bolt M10x60mm ID.7 to attach the
crash frame to the dural screw.