



CF18

KTM 950 Adventure

Kit for the left side

No.	Description	Cat.no.	Pcs
1	Crash bar		1
2	Steel adapter with thread	X30	1
3	Steel adapter on bar	X20	1
4	Bolt M8x25mm hex head	815	2
5	Nut M8 – safety	809	2
6	Pad M8 – plane	802	6
7	Bolt M8x70mm	841	1
8	Bolt M8x40mm	828	1
9	Dural. cylinder d=13mm	86	1
10	Plastic plug into the tube 25mm	X19	1
11	Tape 3M		1
12	Advertising sticker RDmoto		1

Kit for the right side

No.	Description	Cat.no.	Pcs
1	Crash bar		1
2	Steel adapter with thread	X30	1
3	Steel adapter on bar	X20	1
4	Bolt M8x25mm hex head	815	2
5	Nut M8 – safety	809	2
6	Pad M8 – plane	802	6
7	Bolt M8x70mm	841	1
8	Bolt M8x40mm	828	1
9	Dural. cylinder d=13mm	86	1
10	Plastic plug into the tube 25mm	X19	1
11	Tape 3M		1
12	Advertising sticker RDmoto		1

Installation:

Make the installation of the crash bar according to the instruction on the below attached photos.

The installation of the crash bar for the left and right side is the same.

The crash protectors with the logo RDmoto is not included in this type of crash bar.

Warning – we recommend to use safety glue on threads of all bolts (moderate strong – blue colour).

The right side:



steel adapter with thread M10 + steel adapter on bar $\varnothing = 25\text{mm}$ + two bolts M8x25mm + four pads M8 (plane) + two nuts M8 (safety)



plastic plug into the tube

bolt M8x40mm + pad M8 (plane) + duralumin cylinder d=13mm

bolt M8x70mm + pad M8 (plane)

The left side:



steel adapter with thread M10 + steel adapter on bar $\varnothing = 25\text{mm}$ + two bolts M8x25mm + four pads M8 (plane) + two nuts M8 (safety)