

# CF65

## BMW F650 (96)

| Mounting kit |                        |         |     |
|--------------|------------------------|---------|-----|
| ID           | Description            | Cat.no. | Pcs |
| 1            | Steel rod 10x165x30x30 | -       | 1   |
| 2            | Dural. cylinder – 17mm | 84      | 2   |
| 3            | Washer M10             | 804     | 2   |
| 4            | Nut M10                | 961     | 2   |

### Instructions

- 1.) Prepare both frames and fit them in lower part first.
- 2.) Put steel rod through the frame and tighten it using two cylinders, two washers and two nuts M10.
- 3.) Tighten upper part using original bolts.

