



CS16KD

BMW F900XR 2019-

Mounting kit:

ID.	Description	Cat. No.	Pcs.
1	Steel adapter for spring – right side	X160	1
2	Steel adapter – left side	X147	1
3	Bolt M10x12mm	1069	4
4	Washer M10	804	6
5	Steel insert (l=11mm)	242	2
6	Spring (large) for mounting stands	X57	1
7	Spring (small) for mounting stands	X93	1
8	Bolt M10x25mm	1066	2
9	Bolt M8x20mm	823	2
10	Sticker	-	1

Warning:

We recommend using medium strength (blue) thread glue during assembly.

Installation :

1. Mount the ID.1 adapter on the right side with ID.9 screws. M8 threads are prepared in the motorcycle frame.
2. Release the footrest holder on the left side and slide the ID.2 adapter under it. Tighten the footrest holder again.
3. Mount the ID.3 screws in both adapters, they will serve as stops for the stands. Mount from the inside of the adapters.
4. Take the stand, insert the steel inserts ID.5 into it and mount the stand in the adapters with the screws ID.8.
5. Prepare the spring assembly and stretch it over the studs of the stand and adapter on the right side.

