

H70N

Honda CBR600RR

Left side :

Right side :

ID.	Description	Cat.No.	Pcs
1	Steel washer	X1/10	1
2	Bolt M12x65x1,25mm	940	1
3	Dural.roller - l=44,5mm	DV-271/10	1
4	Bolt M10x65mm	943	1
5	Steel adapter	783	1
6	3M tape		3

ID.	Description	Cat.No.	Pcs
1	Steel washer	X1/10	1
2	Bolt M12x65x1,25mm	940	1
3	Dural.roller - l=44,5mm	DV-271/10	1
4	Bolt M10x65mm	943	1
5	Steel adapter	784	1
6	3M tape		3



Installation :

1. Remove the original plastic on both sides of the motorcycle.
2. Take the steel adapters and stick 3M tapes ID.6 into them.
3. Remove the original M12 screw on the left side and put the steel adapter ID.5 on the frame and tighten it with the M12x65x1.25mm screw ID.2.
4. Repeat the same procedure for the right side.
5. Now you can mount the side plastics back.
6. Take the duralumin roller ID.3 (l=44.5 mm) and insert it into the slider from the back.
7. Now use the M10x65mm screw (ID.4) with the washer (ID.1) to attach the slider to the steel adapter.

Using the H70N assembly kit, you can mount all types of our sliders marked PH, PHV, SL and SD.

We recommend using glue on all threads.

Illustrative photo of mounting points.



