

Y49-2

Yamaha MT-09 / SP Yamaha Tracer 9 / GT

Kit for left side

ID.	Description	Cat.No.	PC
1	AL insert to the protector	X1	1
2	Bolt M10x130x1,25mm	905	1
3	Dural. roller l=57mm	1368	1

Kit for right side

ID.	Description	Cat.No.	PC
1	AL insert to the protector	X1	1
2	Bolt M10x85x1,25mm	934	1
3	Dural. roller l=24mm	1367	1

Instruction :

Install the left and right protectors in the bracket according to the photo below. Thread AL inserts (ID.1) on both screws. Insert the duralumin roller (ID.3) under the protector on the left side and tighten it with the screw (ID.2). Insert the duralumin roller (ID.3) under the protector on the right side and tighten it with the screw (ID.2). Finish one side first and then assemble the other.

Note: We recommend using medium strength thread glue for all bolts (blue color).

