

SpeedoHealer^{CAN} | User Manual

CAN-BUS compatible speedometer calibrator

1. Foreword

Congratulations on your purchase of a SpeedoHealer CAN (SH-CAN) calibrator module.

This product can be installed on most motorcycles/ATVs with CAN-BUS system. It comes with a universal wiring harness and high-quality quick connectors.

To make the installation as straightforward as

possible, we offer bike-specific Supplementary Manuals (new ones are added regularly). These are accessible through our website and also from the 'SpeedoHealer CAN' app.

For more information on this product, please visit:
www.healtech-electronics.com/SH-CAN

2. Installation

Before starting the installation, please make sure the SH-CAN unit is compatible with your vehicle. Check compatibility by using the **Product Advisor** on our website. If your bike model is not listed yet, please contact us for advice.

Disclaimer:

Do not attempt to install the product if you don't have basic mechanical skills. HealTech Electronics Ltd. and its distributors shall not be liable for any loss or damage caused by improper installation. If in doubt, please consult with your dealer.

1. Install the 'SpeedoHealer CAN' app from HealTech Electronics Ltd. on your phone.
2. Launch the app. Swipe left to reach the Main Menu. Tap the QuickStart menu button. Tap 'No' when asked whether you have installed the product.
3. Select your vehicle from the list.
4. Install the SH-CAN module as per the illustrated installation guide. (Contact us if there's no Supplementary Manual for your vehicle yet.)
5. After successful installation run the QuickStart from the app, but this time tap 'Yes' on the popup, as the SH-CAN module is already installed.
6. Read and follow the app instructions carefully.

3. Device compatibility / application download links:

📱 iOS devices:

Compatible with iPhone/iPad devices running iOS 15.6 or newer. **To download the latest 'SpeedoHealer CAN' app scan the barcode or visit the link below:**

<https://apps.apple.com/hu/app/speedohealer-can/id6737591975>



📱 Android devices:

Compatible with Android devices running Android 5.0 (Lollipop) or newer. **To download the latest 'SpeedoHealer CAN' app scan the barcode or visit the link below:**

https://play.google.com/store/apps/details?id=com.healtech.sh_can



4. Warranty

HealTech Electronics Ltd. guarantees this product against defects in material and workmanship for a period of two (2) years.

The warranty period starts from the date of the original purchase as shown on the invoice.

5. Specifications

- Supply voltage: +8V to +20V
- Max. supply current at 12V: 150 mA
- Operating temp: -40°C to +80°C (-40°F to +176°F)
- Unit size: 50 x 37 x 17mm (1.96 x 1.45 x 0.66 inches)
- Reverse polarity and transient protection
- Waterproof (IP68)

- Regulatory certifications:

CE FCC  210-133697 **SRRC** RoHS